RISE


RISE MODE AURA ICE ARGB

QUICK INSTALLATION GUIDE


EN- To make the download of the temperature software, scan the QR code below.

PT- Para efetuar o download do software de temperatura faça o escaneamento do QR Code abaixo.


BRACKET COMPONENTS




BRACKET COMPONENTS




RADIATOR INSTALLATION




PUMP BRACKET SETUP




INTEL BACK PLATE




AMD BACK PLATE




INTEL LGA1366/115X/17XX SETUP



AMD AM5/AM4/AM3/FM2 SETUP




INTEL LGA2066/2011 SETUP



FAN/PUMP CABLE INSTALL

A. MULTIPLE FANS AND PUMP RGB CABLE CONNECT WITH EACH OTHER.






FAN/PUMP CABLE INSTALL

B. MULTIPLE FANS AND PUMP RGB CABLE CONNECT WITH EACH OTHER.






FAN/PUMP CABLE INSTALL


C. MULTIPLE FANS AND PUMP RGB CABLE CONNECT WITH EACH OTHER






FAN/PUMP CABLE INSTALL

D.CONNECT THE FANS TO "CPU_FAN" ON THE MOTHERBOARD VIA THE ADAPTER CABLE.



FAN/PUMP CABLE INSTALL

E.CONNECT THE PUMP TO "CPU_OPT" ON THE MOTHERBOARD.



Attention: During the shutdown state, it is important to ensure that the fan pin is covered by a cap to prevent it from coming into contact with the chassis plate. Failure to do so may result in a short circuit, which can potentially cause damage to the machine.

