RISEMODE

COOLING PAD GALAXY X3 RGB



USER MANUAL


RISEMODE.COM

RISE
COOLING PAD
GALAXY X3 RGB

Cooling Pad

Ergonomic design; Flat structure.
All of the corners of cooling pad have been handled carefully, to protect the notebook.
The stand at the bottom body has the function of height adjustment which enables the user to find proper angle easily.
1000-1200RPM speed, lower the noise while dissipate the heat.
Extra USB port and power switch design. Two extra USB port for connecting more USB device.
A circle of dazzling LED light bars can visually add a sense of color, whether you are focused on the office or immersed in the game, can enhance your gaming experience, allowing you to make the most out of it.
Suitable for 10-16 inch laptop.

RGB Backlit Adjustment



①One-button to switch 10 modes

Modes:
- ·Colors Fowing-1
- ·Colors Fowing-2
- ·Red
- ·Green
- ·Blue
- ·Cyan
- ·Purple
- ·Breathing mode
- ·Horse race lamp mode
- ·Color gridient mode(The last mode, you can also hold and press the button for 3 seconds to directly turn off light in any mode)

②Mobile phone holder

Steps:

Put the cooling pad on the desktop, open the holders at the bottom, store your laptop on the cooling pad.

Insert the USB cable of the cooling pad into the USB port of your computer, and make sure the connection is unobstructed.

Rotate the speeder to control the fan speed and turn on/off cooler.

Warm tips:

This product can only be power supplied by DC 5V voltage.
You can adjust the viewing angle easily based on your personal preference.